



SPEKTRUM® AS3X® Receiver Quick Start Programming Guide

Step 1

Transmitter Setup

- Set all transmitter settings to default.
- Important:** The Aileron, Elevator and Rudder settings in the transmitter must remain at their factory default values. Settings for reverse, sub trim, travel adjustment, expo and dual rate must be done in the App only.




To get more information, including information on downloading the Spektrum AS3X Mobile Programming application, scan this QR code or visit www.SpektrumRC.com/AS3X

Step 2

Installing the Receiver

- Install the receiver in one of 8 possible orientations using double sided tape.
- The servo ports must be facing the front or rear of the aircraft.
- The receiver must be mounted parallel to the roll, pitch and yaw axis (NOT ANGLED).




AR636 shown

Step 3

Binding

- Insert the bind plug into in the receiver bind port and power on the receiver. The LED should blink to indicate the receiver is in bind mode.
- Bind the transmitter to the receiver at low throttle. Refer to your transmitter's manual for details on how to bind to your specific transmitter.



AR636 shown

Step 4

Installing the AS3X Mobile Application*

- To install the Spektrum AS3X App on your iOS or Android mobile device, visit www.SpektrumRC.com/AS3X or download from the Apple App Store or Google Play store.
- Once installed, start the App.



*Minimum system requirements:
iOS 6.0, iPhone 4, iPad 4th gen and Android 4.0

Step 5

Connecting to the Receiver

- Connect the servo plug on the audio interface cable to the BIND/PROG port on your receiver.
- Power the receiver through any open channel.
- Connect the audio plug on the interface cable to the audio jack on your mobile device. The volume **MUST** be turned up to full.



If your Android device does not recognize the receiver*

- Ensure you have secure receiver data port and audio data port connections. If the receiver is being connected for the first time, the App will automatically open in Model Wizard in the Model Setup screen.
- Disconnect the audio plug from the device.
- Separate the servo plugs in the middle of the interface cable.
- Flip the device servo plug 180 degrees and re-connect the servo plugs.
- Re-connect the audio plug to the device.

*Does not apply to iOS Devices.

Step 6

Plug servo leads into assigned ports

Typical Servo Port Assignments*:

Normal Model Type	Delta / Elevon Model Type	Bind/Prog
• Port 1: Throttle	• Port 1: Throttle	Port 1
• Port 2: Aileron	• Port 2: Right Aileron	Port 2
• Port 3: Elevator	• Port 3: Left Aileron	Port 3
• Port 4: Rudder	• Port 4: Rudder	Port 4
• Port 5: Gear/ Flap	• Port 5: Gear	Port 5
• Port 6: Left Aileron (if equipped with dual servos)	• Port 6: Aux 1	Port 6

*AR636 shown for reference. Port assignments will be similar for all AS3X receivers. Refer to your receivers manual for more information.

Step 7

Model Setup

- In the setup Wizard, follow and complete each step. Help functions are available in each screen to assist.
- When model setup is done, complete final setup of the EXPO, D/R and Gains for each flight mode.

Visit www.SpektrumRC.com/AS3X for more information and to view video's on how to program your new AS3X receiver.

Step 8

Preflight Checks

- Test all flight modes are operating as expected (D/R, Gains and EXP0).
- Test servo direction (servo direction must be set using the App and not the transmitter).
- Test gyro's are correcting in the proper direction.

Control Direction Test

Move the controls on the transmitter to make sure the aircraft control surfaces move in the proper direction.

Transmitter Command	Aircraft Reaction
Up Elevator Command	Elevator
Stick Right	Aileron
Stick Left	Rudder
Elevator	AS3X Control Direction Test
Aileron	Once you are sure the aircraft responds correctly, move the aircraft as shown to ensure the AS3X system moves the control surfaces in their proper direction.
Rudder	Aircraft Movement

Schritt 5

Für mehr Informationen über die mobile AS3X App und den Download besuchen Sie bitte www.SpektrumRC.com/AS3X oder scannen den QR Code.



SPEKTRUM[®] AS3X Empfänger Quick Start Programmieranleitung

Schritt 1

Senderprogrammierung


- Alle Sendereinstellungen müssen auf den Grund- oder Standardeinstellungen programmiert sein.
- WICHTIG:** Die Einstellungen der Quer-, Höhen- und Seitenruder müssen auf den Werkseinstellungen des Senders sein. Die Einstellungen für Reverse, Sub Trim, Weg, Expo und Dual Rate werden nur in der App vorgenommen.



Schritt 2

Einbau des Empfängers


- Bauen Sie den Empfänger in einer der 8 möglichen Einbaulichtungen mit doppelseitigen Klebeband an.
- Die Servoanschlüsse (Ports) müssen zur Front oder Heck des Flugzeuges zeigen.
- Der Empfänger muss parallel zur Roll-, Nick- oder Seitenachse eingebaut sein. (NICHT ANGEWINKELT)



Schritt 3

Binden

- Stecken Sie den Bindestecker in die Bindepforte des Empfängers und schalten ihn ein. Die LED auf dem Empfänger sollte nun blinken und damit anzeigen, dass sich der Empfänger im Bindemode befindet.
- Binden Sie den Sender an den Empfänger mit Gasknöpfen auf Leerlauf / Motor Aus. Führen Sie den Bindevorgang gemäß der spezifischen Information in der Bedienungsanleitung des Senders durch.



Schritt 4

Installation der AS3X App*

- Um die Spektrum AS3X App auf Ihrem iOS oder Android mobilen Gerät zu installieren besuchen Sie bitte www.SpektrumRC.com/AS3X oder laden die App vom Apple App Store oder Google Play Store.
- Starten Sie nach der Installation die App.



*Mindest Systemanforderungen:
iOS 6.0, iPhone 4, iPad 4, Gen und Android 4.0

Schritt 8

Vorflugkontrolle

- Prüfen Sie ob alle Flugmodi wie erwartet arbeiten (D/R, Gain und EXP).
- Prüfen Sie die Laufrichtung der Servos (Bitte beachten die Laufrichtung wird über die App und nicht über den Sender eingesetzt).
- Prüfen Sie ob die Kreisel in die korrekte Richtung arbeiten.

Steuerkontrolltest

Bewegen Sie die Kontrollen auf dem Sender um sicherzustellen, dass die Ruder in die richtige Richtung arbeiten.

	Senderbefehl	Flugzeugreaktion
Höhenruder	Höhenruder nach oben	
Querruder	Querruder	
Seitenruder	Steuerknüppel rechts	
	Steuerknüppel links	

AS3X Kontrolltest

Haben Sie sich davon überzeugt, dass die Steuerbefehle korrekt umgesetzt werden bewegen Sie das Flugzeug wie abgebildet um die Funktion des AS3X System zu überprüfen.

	Flugzeugbewegung	AS3X Reaktion
Höhenruder		
Querruder		
Seitenruder		